


Guide: Firmware Update

Öffnen Sie den Ordner **KNX_Firmware_Update_** und führen Sie die Datei „Hugo Mueller KNX Firmware Update.exe“ aus.

The screenshot shows the 'Hugo Mueller KNX Firmware Update' application window. The interface includes the Müller logo, a 'Bus Connection' section with a 'Connection String' field set to 'Type=USB', a 'Connect' button, and a 'Closed' status. Below this is a 'Discovered Interfaces' section listing two interfaces: 'KNX-USB Interface (TP) (1.1.1)' and 'KNX IP LineMaster 762.1 secure 172.18.65.141'. A 'Refresh' button is located to the right of the interface list. Two red arrows point to specific elements: one points to the 'KNX-USB Interface (TP) (1.1.1)' entry, and the other points to the 'Connect' button.

1. Interface wählen

2. Auf „Connect“ klicken



Bus Connection

Connection String: Connected

Discovered Interfaces

KNX-USB Interface (TP) (1.1.1)

- KNX IP LineMaster 762.1 secure 172.18.65.141
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.14.0)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.241)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.242)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.243)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.244)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.245)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.246)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.247)
- KNX IP BAOS 777 PM/VT 172.18.65.173
- 00-24-6D-02-83-DF 172.18.65.33
- 224.0.23.12 on 172.18.64.201

Firmware Update


Individual Address: Connected

Filename: GS68_21_KNX2_Update_Rev_274.firmware
Size: 153 KB
State: **Firmware valid -> Updating from v0.1.14 to v0.1.15**

☐ Trace Download

4. Firmware-Update-Datei auswählen (.firmware)

5. Auf „Start Download“ klicken



6. Der Fortschritt des Updates kann über den Balken verfolgt werden

Hugo Mueller KNX Firmware Update

Discovered Interfaces

- KNX-USB Interface (TP) (1.1.1)
- KNX IP LineMaster 762.1 secure 172.18.65.141
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.14.0)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.241)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.242)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.243)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.244)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.245)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.246)
- KNX IP LineMaster 762.1 secure 172.18.65.141 (15.15.247)
- KNX IP BAOS 777 PM/VT 172.18.65.173
- 00-24-6D-02-83-DF 172.18.65.33
- 224.0.23.12 on 172.18.64.201

Refresh

Firmware Update

Individual Address: 1.1.17 Disconnect Connected

Select firmware file Filename: GS68_21_KNX2_Update_Rev_274.firmware
Size: 153 KB
State: Download Finished successfully

Start Download Stop Download

7. Nach erfolgreichem Download erscheint die Meldung „Download finished successfully“